



Somfy Altus Motor Wiring Diagram

LT50 ALTUS RTS



LT50 RTS CMO



Note: Only RTS and ILT motors can be wired in parallel.

LT50 ALTUS RTS AND LT50 RTS CMO MOTOR WIRING COLOR CODE

120V AC	CODE
BLACK	(H) HOT
WHITE	(N) NEUTRAL
GREEN	(G) GROUND